


# 16722 STi Duty One GNB



|      |                           |   |      |                         |   |      |                    |   |      |                    |   |      |                  |   |      |                      |   |
|------|---------------------------|---|------|-------------------------|---|------|--------------------|---|------|--------------------|---|------|------------------|---|------|----------------------|---|
| 1-01 | Body Seat                 | 1 | 1-14 | Mag. Catch              | 1 | 1-30 | Screw              | 1 | 1-34 | Screw              | 2 | 3-01 | BB Carry Parts   | 1 | 7    | Valve Combination    |   |
| 1-02 | Body Cover                | 1 | 1-16 | Safety Catch            | 1 | 1-31 | Axis               | 1 | 1-35 | Axis               | 1 | 3-02 | HOP-UP Parts     | 1 | 7-01 | Valve Chamber        | 1 |
| 1-03 | Hammer Stopper            | 1 | 1-17 | Back Cover Catch        | 1 | 1-32 | Axis               | 1 | 1-37 | Screw              | 1 | 3-04 | Outer Barrel     | 1 | 7-02 | Valve Cover          | 1 |
| 1-04 | Frame                     | 1 | 1-19 | Trigger Connector       | 1 | 1-33 | Screw              | 4 | 1-38 | Stopper Spring     | 1 | 3-05 | BB Holder        | 1 | 7-03 | Valve Ring           | 1 |
| 1-05 | Grip(L)                   | 1 | 1-20 | Safety Catch            | 1 | 1-36 | Screw              | 1 | 1-40 | Screw              | 1 | 3-06 | Internal Barrel  | 1 | 7-04 | Piercer Seal         | 1 |
| 1-06 | Grip(R)                   | 1 | 1-21 | Fixing Axis             | 1 | 1-37 | Screw              | 2 | 1-42 | Fixing Axis Spring | 1 | 3-07 | BB Pusher        | 1 | 7-05 | Fixing Ring          | 1 |
| 1-07 | Back Cover                | 1 | 1-22 | Washer                  | 1 | 1-38 | Stopper Spring     | 1 | 1-43 | Axis               | 1 | 3-08 | Screw            | 1 | 7-06 | Valve Seal           | 1 |
| 1-08 | Recoil Spring Guide       | 1 | 1-23 | Trigger Spring          | 1 | 1-39 | Recoil Spring      | 1 | 1-44 | Screw              | 1 | 3-09 | Barrel Tip       | 1 | 7-07 | O-ring               | 1 |
| 1-09 | Recoil Spring Guide Cover | 1 | 1-24 | Slide Stop Spring       | 1 | 1-40 | Screw              | 1 | 1-42 | Fixing Axis Spring | 1 | 4-01 | Hammer           | 1 | 7-08 | O-ring               | 1 |
| 1-10 | Slide Cover               | 1 | 1-25 | Hammer Spring           | 1 | 1-41 | Screw              | 1 | 1-42 | Fixing Axis Spring | 1 | 4-02 | Attacked Block   | 1 | 7-09 | Washer               | 1 |
| 1-11 | Trigger                   | 1 | 1-27 | Back Cover Catch Spring | 1 | 1-42 | Fixing Axis Spring | 1 | 1-43 | Axis               | 1 | 4-02 | Attacked Block   | 1 | 7-10 | Filter               | 1 |
| 1-12 | Slide Stop                | 1 | 1-28 | Safety Catch Spring     | 1 | 1-43 | Axis               | 1 | 1-44 | Screw              | 1 | 5    | Mag. Combination |   | 7-11 | Piercer              | 1 |
|      |                           |   |      |                         |   | 1-44 | Screw              | 1 | 2-01 | Slide              | 1 | 5-01 | Mag. Body        | 1 | 7-12 | Valve                | 1 |
|      |                           |   |      |                         |   | 2-01 | Slide              | 1 | 2-02 | Front Sight        | 1 | 5-02 | Mag. Cover       | 1 | 7-13 | Valve Spring         | 1 |
|      |                           |   |      |                         |   | 2-02 | Front Sight        | 1 | 2-03 | Aiming Hole        | 1 | 5-03 | BB Follower      | 1 | 8    | Knob Combination     |   |
|      |                           |   |      |                         |   | 2-03 | Aiming Hole        | 1 |      |                    |   | 5-04 | Mag. Base        | 1 | 8-01 | Knob Seat            | 1 |
|      |                           |   |      |                         |   |      |                    |   |      |                    |   |      |                  |   | 8-02 | Knob Cover           | 1 |
|      |                           |   |      |                         |   |      |                    |   |      |                    |   |      |                  |   | 8-04 | Piercing Level Screw | 1 |
|      |                           |   |      |                         |   |      |                    |   |      |                    |   |      |                  |   | 8-05 | Axis                 | 1 |
|      |                           |   |      |                         |   |      |                    |   |      |                    |   |      |                  |   | 8-06 | Screw                | 2 |

ActionSportGames A/S

Bakkegaardsvej 304  
DK-3050 Humlebaek  
Denmark

Phone: +45 8928 1888  
Fax: +45 4919 3160  
sales@actionsportgames.com

actionsportgames.com